

Nick Kalantas Advisors LLC dba TERRAZZO GRANITECH USA
2750 NW 3rd Ave
Unit 13
Miami, FL 33127 US
+1 786 396 6810
www.terrazzo-usa.com

Recommended steps – TERRAZZO GraniTech Sample Kit

- Note: Microterrazzo 600 Q is applied in 2 coats, TERRAZZO GraniTech Medium in 3 coats and TERRAZZO GraniTech Fine is applied after two layers of TERRAZZO GraniTech Medium have been applied first, or it can be applied with a brush only after diluting it more than one usually would.
- Note: Use a no-black-marks beveled stainless steel trowel to avoid black marks – contact us to purchase one!
- Note: A 120 grit is usually used for TERRAZZO GraniTech Medium and TERRAZZO GraniTech Medium, while a 80 grit may be used for Microterrazzo if one feels the 120 grit is not enough. This is highly dependent on application, a clean application with no chatter or trowel marks requires minimal sanding.
- Videos and tutorials can be seen [here](#), including a step-by-step [guide](#) for TERRAZZO GraniTech Medium

Before making the samples, please follow the steps below:

Mixing Instructions

- TERRAZZO GraniTech Fine Finish (32 oz container): Add 5 ml of water and pigment and mix thoroughly.
- TERRAZZO GraniTech Medium & MicroTerrorazzo Finishes (32 oz containers): Add 10 ml of water to each and mix thoroughly. Add pigment to the TERRAZZO GraniTech Medium finish, the Microterrazzo can be left in its signature white.
- Quartz primer: [Apply](#) as is (no water).

Application Steps

1. Apply the primer using a shorthair and allow it to dry for several hours (ideally overnight). Apply evenly!
2. Apply Medium and MicroTerrorazzo samples first, two boards of medium and one coat of Microterrazzo.
3. The following day, after sanding with 120-grit, apply the Fine Finish over one of the Medium samples using a no-black-marks stainless-steel beveled Bianco trowel. If you don't have one contact us to purchase, this trowel is crucial for the installation of TERRAZZO GraniTech Fine.
4. For MicroTerrorazzo, sand between coats with 80–180 grit; a second coat may be applied if desired. Do not hold the trowel in an angled manner, it will drag the embedded aggregates and create chatter – see the following [video](#) for more on this. Scrape and smoothen out after the initial spreading of the material.
➔ Apply TERRAZZO GraniTech Medium and Fine in 1mm thick coats and Microterrazzo in 2mm coats! Scrape excess material beyond the recommended thickness!

Sealers (8 oz containers) – video showcasing proper application can be seen [here](#)

- Allow 48 hours of drying time before applying sealers. Then sand once again as described above and clean well, removing any dust prior to proceeding with the sealer application.
We recommend one sealer on each board, to provide you with a clear picture of the visual outcome of each sealer. Roll onto a paint tray and apply a thin coat in criss-cross motions as demonstrated in the video.
Sand lightly between sealer coats using a 320 grit to remove any “fish eyes”. Do not sand excessively to remove the sealer, that will undo the work completed. Sand between sealer coats, including the final coat! Remove dust.
- Satin Floor Sealer: Single-component.
- Matte Floor & Wall Sealers: Two-component systems.
 - Floor Sealer Ratio: 5.25 : 1 (Part A : Part B)
 - Wall Sealer Ratio: 9 : 1 (Part A : Part B)
- For your sample kit, we've pre-measured the correct ratios — simply mix thoroughly and apply using a mohair roller